

Your Futaba R7208SB/R7308SB programming can be updated easily online. When functions are improved, the update file can be downloaded from our website.

For more information, check out web site for FAQ regarding updating this product.


*The display screen is an example. The screen depends on the PC.

Required for update (Purchase separately)

CIU-3 or CIU-2




CGY750/GY701/GY520 Extensions



PC (Access is possible by the web)

Preparations

1. Install the driver for the CIU-3/CIU-2 onto your PC.




- ◆ When the **CIU-3** is first connected to the PC, once the CIU-3 is connected to the PC, download the recommended driver software Using Windows Vista, the "Found New Hardware Wizard" window appears on the screen. Click "Locate and install driver software".
- ◆ When the **CIU-2** is first connected to the PC; the "Found New Hardware Wizard" window appears on the screen. Install the drivers download from local Futaba Dealers Website.
- ◆ Refer to the manual of the CIU-3/CIU-2 for further information.

Updating procedure

1. Download the zip file of the update data from our website or your local distributor's website.


<http://www.rc.futaba.co.jp>

<https://futabausa.com>




2. Extract the zip file on your computer.


*The software of R7208SB and R7308SB is common.




3. Connect as shown in the figure.




4. Turn on the receiver power while pressing down the switch.




5. LED flash red once, release the switch.




6. Press the switch again.




7. Release the switch when the solid orange.



8. Execute the update file copied to the PC.



Write




OK


9. Operate the PC update. (The receiver should keep orange on.)

Wait



Don't turn off the power !



Flickers **GREEN** during update



LED solid **GREEN**



10. The **GREEN LED** on the R7208SB/R7308SB lights up when the update is complete. A completion message box will appear on your PC. Click OK.
11. Turn off the power switch of your R7208SB/R7308SB and remove the CIU-3/CIU-2.
12. Be sure to check the each function before use.

V1.1 UPDATE

- Fixed an issue where some transmitters could not be linked.

Back of receiver



Receivers whose serial number is 2351 or earlier are eligible. Receivers from 2352 onwards do not need to be updated.